
## Joint Cleaning & Greasing Shock S (5) Pressurize to 15-17 bar (200-250 psi) Seatstay Swingarm

Your FI's linkage joints are higly precision machined, using milled "PEEK" bushings and CNC "HART-COAT" treated pivot/bolts. This system insures high responsiveness and years of life with only regular cleaning and greasing. After riding in wet conditions or bike washing muddy water may enter and dry up into the joints, leaving a thin abrasive film in the long run. After several wetting and dryings sand particles will create a true abrasive layer sticking to the bushings. This could wear prematurely the Hart-Coat pivot surface. Therefore remove every dirtfrom the bushing, and bring it to its original cream-white color, avoid using sharp tools, aggressive solvents or abrasives. Inadequate joint cleaning voids the limited warranty. Always use quality tools and insure a precise and complete fit. When reassembling liberally grease the pivot surface and thread (use quality waterproof grease). Grease will prevent alluminium thread seizing and water/dirt entering. We recommend to protect your shock with a shock boot when riding in wet condition.

This prevent shock shaft and seal premature wear.

(a) Unscrew with 2.5 mm allen key.
(b) Push the Ø10 axle with a Ø8mm flat and smooth rod.


Reassemble carefully alligning bushings and seatstay mountings.



Unscrew the pivot/bolt using a 6mm allen key. Reassemble carefully alligning the thin alluminium thread (MIOxImm). Grease well.

(a) Unscrew with 2.5 mm allen key. (b) Push the øl2 axle with a ø8mm flat and smooth rod.

Reassemble carefully alligning frame mountings and bushings.
Insert the swingarm axle from left to right. keeping the small hole on the chainside.





Unscrew the pivot/bolt using a 6mm allen key. Reassemble carefully alligning the thin alluminium thread (M10x1mm). Grease well.

(a) Unscrew with 2,5 mm allen key.
(b) Push the Ø10 axle with a Ø8mm flat and

Reassemble carefully alligning frame mountings and bushings.

smooth rod.





Shock Spring Removing:

(a) Completely unscrew the preload threaded ring.

(b) Pull out the spring round shoulder through its lateral cut.

WARNING: do not scratch the shock shaft's smooth surface:

Reassemble in reversed sequence.

⚠ Spring round shoulder: Imm grooved side must centre the spring base: rounded side,extemal.

any problem ? cont@ct us! -