

HyperGrips

**We recommend to secure glue
HyperGrips to your handlebar.**

PVA glue (water based, commonly used for cardboard and wood) will offer a good glueing that is also easy to remove without damaging grips nor handlebar surface.

INSTALLATION

Apply 1cc. of glue onto handlebar and 1cc. inside grips, slide grips onto handlebar, clean the excess glue, adjust grips position and let the glue dry for at least 24 hours in a dry room.

info@extralite.com

